



Jimco Vents

General Installation for B.U.R.

1. Select location over installation joints.
2. Cut 4" hole through felts and insulation. Do not puncture vapor barrier (if used)
3. Center vent over opening. Embed in asphalt cement or steep asphalt. Make sure the opening is free of all materials
4. Flash base flange with 2 plys of felt, asphalt cement, or steep asphalt. Extend first ply of felt 6" beyond flange and the second ply 9" beyond flange.
5. Pour flood coat of bitumen and gravel to the base of the roof vent.

For other roofing systems, see manufacturer's installation specifications

500 Distribution Parkway, Collierville TN 38017 USA

• Tel: (901) 853-5001 • Toll Free: (800) 888-8312 • Fax: (901) 853-5008 • website: www.ipscorp.com